
OXVA




UniTech 3.0

NeXlim 2

USER MANUAL

PRODUCT STRUCTURE



SPECIFICATIONS

Size:	127.5*28.5*17.5mm
Capacity:	4ml/2ml(TPD)
Screen:	0.85 inch TFT
Output Voltage:	3.2-4.2V
Battery Type:	Built-in 2000mAh
Charging:	Type-C 5V/3A

JUICE FILLING

Fill the e-juice into the cartridge.



TIPS

1. After filling the e-juice into a new cartridge, please wait for at least 5-8 minutes before vaping to avoid dry burning.
2. After filling the juice, please close as soon as possible to avoid leaking.

INSTRUCTIONS

1. Turn on/off:
   Press the button 5 times to turn it on/off.
2. Vaping:
   While the device is on, draw to vape.The device will stop working when the vaping is longer than 8s due to safety protection.

3. Adjust Mode:
   Press the button 2 times to adjust your preferred mode.
4. Adjust Output:
   Press the button 3 times to adjust your preferred wattage.
5. Adjust Theme:
   Press the button 4 times select the theme. Click the button 1 time to lock your preferred theme.
6. Vaping Animation
   Press the button 6 times to turn on/off the Vaping Animation.
7. Reset Puffs:
   Press the button 7 times to reset the puff count.
8. Screen Prompts

BATTERY LOW:	Low Battery
NO POD:	The cartridge is not detected.
SHORT:	Short Circuit
TIMEOUT:	The vaping time is over 8s.
TEMP HIGH:	The temperature of PCBA is too high.

9. E-manual:
   Long press to read the operation guidance.

ATTENTION

* Please keep away from inflammable and explosive materials to avoid injury.
* Please don't leave the device unattended while charging.
* Please use OXVA brand components and accessories to avoid device damage or health problems.

WARRANTY POLICY

Thank you for purchasing OXVA products. OXVA will fulfill the following terms and conditions in order to offer the original buyer with repair or replacement under warranty:

1. The warranty covers defects in materials or workmanship under normal use for 90 days from the purchase date. The warranty covers the repair or replacement of any damaged parts.

2. This warranty may be disqualified as a result of the following circumstances:
   * The customer does not give this warranty card or the original receipt for purchase.
   * Merchandise failure or damage is caused by improper use or unauthorized adjustments.
   * Merchandise failure or damage caused by extreme force or impact, as well as operating conditions that are not recommended.See the user handbook for details.
   * Merchandise failure or damage caused by exposure to water or other conducting liquids.
   * Merchandise failure or damage caused by using non-OXVA brand accessories.

3. This warranty does not cover personal or consumable items like coil heads, USB cables, and mouthpieces.

For more information please visit our website at www.oxva.com
Or email us at support@oxva.com

PURCHASE INFORMATION

Product Model: _____

Date of Purchase (Based on the date from receipt of purchase):

Day: _____

Month: _____

Year: _____

Store Information:

Store Name: _____

Phone: _____

Store Address: _____

City: _____

Country: _____

Post Code: _____

Customer Information:

Customer Name: _____

Phone: _____

Customer Address:

City: _____

Country: _____

Post Code: _____

* Please use OXVA brand components and accessories to avoid damage of device or health problems.

Shenzhen Future Tech Co., Ltd
Tel: 0086-755-23315089
Email: support@oxva.com
Web: www.oxva.com
Addr: #601, #801, Block 1 of WAN TING BLDG, Baoyuan RD, Xixiang Street, Bao'an, Shenzhen, China.

Scan to Discover OXVA