117 mm

84 mm

封面

VOOPOO

DRAG H40 Pro

Please read the entire manual carefully before using the product.

USER MANUAL

封底

Manufacturer:
Shenzhen Woody Vapes Technology Co., Ltd. (VOOPOO)
Address: Block 1, Shapuyangyong Industry Park, Songgang, Bao'an District, Shenzhen, Guangdong, China
Email: support@voopoo.com
Website: www.voopoo.com

EC REP — VAT SPEED SL
Calle Antonio Salvador N99.1, 28026 Madrid, Spain
E-mail: services@vatspeed-eu.com
Tel: +34 916321624

UK REP — ACMEFOG COMMERCE LTD
Ivy Business Centre Crown Street, Failsworth, Manchester, England, M35 9BG
E-mail: uk_compliance@acmefog.net

封四

Warranty Terms

VOOPOO will provide repair or replacement under warranty according to the following terms and conditions.
A. Warranty provides repair or replacement free of charge for defective eligible VOOPOO merchandise within 90 days of purchase by the end user.
B. This warranty is void in the following circumstances:
* The customer does not provide this warranty card and the original receipt of purchase.
* Product failure or damage is caused by improper use or unauthorized adjustments.
* Product failure or damage because of excessive force or impact and unrecommended operating conditions (see user manual).
* Product failure or damage by cause of water or other conducting liquids.
* Product failure or damage by cause of usage with components unsuggested by VOOPOO.
C. The warranty does not cover personal items or consumable goods and attachments, including but not limited to drip tips, coils, batteries, and USB cables.
D. The warranty does not cover any non-VOOPOO brand products even in case of their direct involvement. VOOPOO reserves the right to the final decision in all warranty cases. VOOPOO may interpret and revise the content of this warranty terms.
For more information, please visit our website at www.voopoo.com or email us at support@voopoo.com.


Warranty Card

Purchase Information
Product Model: ______
Date of Purchase: ______
Store Information
Store Name: ______
Address & Phone: ______
Customer Information
Customer Name: ______
Phone: ______

封三

英语

English




Thanks for your purchase of a VOOPOO product. For better use of all the functions of this product, please carefully read the operation notes and detailed functional instructions before first use. If you have any problem using this product, please contact our local agent or visit our official website at www.voopoo.com.

Parameters

Size	MTL: 116.5*27.5mm / DTL: 111.5*27.5mm
Power Range	5 – 40 W
Battery Capacity	2450 mAh (Built-in)
Output Voltage	3.2 – 4.2 V
Charging Voltage	5 V / 2 A
Resistance Range	0.3 – 3.0 Ω
E-liquid Capacity	5 mL (Standard & US Version) / 2 mL (TPD Version)
Compatible Cartridges	PnP X Cartridge DTL and PnP X Cartridge MTL

Steps




Step 1. Install coil
Take out the coil and insert it from the bottom of the cartridge.
Please ensure that the installed coil is level with the bottom of the cartridge.

Step 2. Fill e-liquid
Open the lid on the filling port, then fill in the e-liquid.
It is recommended to keep the cartridge two-thirds full.


Step 3. Install the cartridge
Insert the cartridge with e-liquid into the device.

Step 4. Start to use the device
After letting it stand for about five minutes, you are free to use the device. You can adjust the airflow by rotating the metal ring at the top of the cartridge for the best vaping experience.

Interface Introductions




Operation Instructions



1. **Power On:** Press the fire button 5 times quickly.
2. **Menu Screen:** Press the fire button 3 times quickly; you can select THEME, CLEAR PUFF, and EXIT settings.
3. **LOCK / UNLOCK** Press and hold the fire button and the "+" button to lock; press and hold the fire button and the "-" button to unlock.
4. **Output Power Adjustment:** Press the "+" or "-" button, each press adjusts the power by one watt. A long press allows for rapid power adjustment.
5. **Charging:** Supports charging with 5V/2A. It is recommended to use the Type-C cable provided by VOOPOO to charge the device.


Prompt Notification



Safety Protection

- Timeout Protection: 8 s
- Short-Circuit Protection
- Overcharge Protection
- Low Battery Protection
- Output Over-Current Protection
- Over-temperature Protection

Maintenance and Cleaning



1. When using the device, you may notice occasional liquid condensation on the outside of the cartridge/tank. This occurs because the liquid is vaporized, and as the vapor cools, it condenses on the outer surface, a common and inevitable physical phenomenon.
2. In daily use, you can often use a wet paper towel to wipe the connection between the device and the cartridge/tank to prevent poor connectivity.
3. If a small amount of condensate is found inside the device during use, we recommend removing the cartridge/tank, reversing the device, and shaking it for a few seconds.

Precautions for Daily Use of Leather and Wood

1. Please avoid scratches from sharp objects or direct friction with rough surfaces.
2. Please avoid contact with corrosive substances such as acids, bases, or alcohol, as well as alcoholic liquids coming into contact with the leather surface.
3. Use a soft cotton cloth to clean dirt from the leather surface.
4. Avoid prolonged exposure to direct sunlight.

Notes


1. When the product is used with nicotine-containing e-liquids:
• Nicotine is a highly addictive substance. No other ingredients of this product are known to be addictive.
• Nicotine benzoate [828-490-9] Toxic if swallowed. Keep out of reach of children. Wash hands thoroughly after handling. Do not breathe vapors. IF SWALLOWED: Immediately call a POISON CENTER or doctor/physician. If medical advice is needed, have the product container or label at hand. Dispose of contents/container to designated place in accordance with local regulations.
2. This product is not recommended for minors, non-smokers, pregnant or breast-feeding women, or anyone at risk of heart disease, depression, and asthma.
3. Please keep the device away from heat, fire, and water. This device should be stored in a cool and shady environment.
4. Please do not drop, throw, or immerse the device in the water.
5. Please turn off or lock the device to avoid accidental firing when you carry it out.
6. Please rationally use the device according to your personal situation. If discomfort occurs, please stop using it immediately.
7. EEE Recycling: This product should not be treated as household waste. Instead, it should be taken to the collection place for the recycling of electrical and electronic equipment.
8. Battery Recycling: The product battery should not be treated as household waste. Instead, it should be taken to the used battery collection place for recycling.
9. It is recommended to use the USB cable provided by VOOPOO to charge the device.
10. If the device is not used for an extended period, it is recommended to charge regularly to prevent deep discharge!
11. The ambient temperature ranges from -5℃-30℃, with humidity 40%-75% RH. Operating temperature of the electronic cigarette: 0℃-40℃!
12. Disassembly is prohibited after product failure!
13. Only for indoor charging, please use a UL-certified USB charger to avoid the danger of fire and explosion!

Warranty

A three-month warranty is provided. During the warranty period, we will provide maintenance and replacement services. Please note the following conditions.
1. It only applies to the products registered on VOOPOO after-sales service website.
2. We assume no liability for damage caused by the user's negligence or accident.
3. We are not responsible for any damage that occurs during use, maintenance or modification that does not conform to the operating instructions in the manual.
4. The defects not caused by processing and the appearance problems are not covered in the warranty.
5. After-sales service for the coil is not provided.

Warm Prompt

Cartridge / Tank Leakage
There is a possibility of e-liquid leakage at high pressure when you travel by air. Therefore, please keep your cartridge / tank away from other important objects.
Deal with Condensate
There may be slight condensation due to the difference between indoor and outdoor temperature when you use the device. It is advisable to take out the cartridge / tank, and shake it downwards.



法语

Français

Merci d'avoir acheté un produit VOOPOO. Pour une meilleure utilisation de toutes les fonctions de ce produit, veuillez lire attentivement les notes d'utilisation et les instructions fonctionnelles détaillées avant la première utilisation. Si vous rencontrez des problèmes lors de l'utilisation de ce produit, veuillez contacter notre agent local ou visiter notre site officiel à l'adresse www.voopoo.com.

Paramètres

Dimensions	MTL: 116,5*27,5mm / DTL: 111,5*27,5mm
Plage de puissance	5 – 40 W
Capacité de la batterie	2450 mAh (intégrée)
Tension de sortie	3,2 – 4,2 V
Tension de charge	5 V / 2 A
Plage de résistance	0,3 – 3,0 Ω
Capacité de e-liquide	5 mL (version standard et US) / 2 mL (version TPD)
Cartouches compatibles	cartouche PnP X DTL et cartouche PnP X MTL

Étapes

Étape 1. Installer la résistance
Sortez la résistance et insérez-la par le bas de la cartouche.
Veuillez vous assurer que la résistance installée est alignée avec le bas de la cartouche.

Étape 2. Remplir le e-liquide
Ouvrez le capuchon du port de remplissage, puis remplissez avec le e-liquide.
Il est recommandé de maintenir la cartouche remplie aux deux tiers.

Étape 3. Installer la cartouche
Insérez la cartouche contenant le e-liquide dans l'appareil.

Étape 4. Commencer à utiliser l'appareil
Après l'avoir laissé reposer pendant environ cinq minutes, vous pouvez utiliser l'appareil. Vous pouvez régler le flux d'air en tournant l'anneau métallique situé en haut de la cartouche pour une meilleure expérience de vapotage.

Présentation de l'interface

Instructions d'utilisation

1. **Mise sous tension :** Appuyez rapidement 5 fois sur le bouton d'activation.
2. **Écran du menu :** Appuyez rapidement 3 fois sur le bouton d'activation ; vous pouvez sélectionner les paramètres THÈME, RÉINITIALISER LES BOUFFÉES et QUITTER.
3. **VERROUILLAGE / DÉVERROUILLAGE :** Maintenez enfoncés le bouton d'activation et le bouton « + » pour verrouiller ; maintenez enfoncés le bouton d'activation et le bouton « - » pour déverrouiller.
4. **Réglage de la puissance de sortie :** Appuyez sur le bouton « + » ou « - », chaque pression ajuste la puissance d'un watt. Un appui long permet un réglage rapide de la puissance.
5. **Chargement :** Prend en charge une charge en 5V/2A. Il est recommandé d'utiliser le câble Type-C fourni par VOOPOO pour charger l'appareil.

Notification d'invite

Protection de sécurité

Entretien et Nettoyage

Précautions pour l'Utilisation Quotidienne du Cuir et du Bois

Remarque

Garantie

Conseils

德语

Deutsch

Parameter

Schritte

Schnittstellenübersicht

Bedienungsanleitung

Hinweismeldungen

Sicherheitsfunktionen

Wartung und Reinigung

Vorsichtsmaßnahmen für den täglichen Gebrauch von Leder und Holz

Hinweise

Garantie

Freundliche Hinweis

意大利语

Italiano

Parametri

Passaggi

Introduzione all'Interfaccia

Istruzioni di Funzionamento

Notifiche di Avviso

Protezione di Sicurezza

Manutenzione e Pulizia

Precauzioni quotidiane per preservare Pelle e Legno

Note

Garanzia

Nota Importante

西班牙语

Español

Parámetros

Pasos

Introducción de la Interfaz

Instrucciones de Funcionamiento

Notificaciones

Protección de Seguridad

Mantenimiento y Limpieza

Precauciones para el Uso Diario del Cuero y la Madera

Notas

Garantía

Aviso Importante

俄罗斯语

Русский

Параметры

Шаги

Описание интерфейса

Инструкции по эксплуатации

Уведомления

Защита безопасности

Техническое обслуживание и чистка

Меры предосторожности при ежедневном использовании кожи и дерева

Примечания

Гарантийный ремонт

Дружеское напоминание

印尼语

Indonesia

Parameter

Langkah-langkah

Pengenalan Antarmuka

Instruksi Pengoperasian

Notifikasi Prompt

Perlindungan Keamanan

Perawatan dan Pembersihan

Tindakan Pencegahan untuk perangkat berbahan Kulit dan Kayu

Perhatian

Garansi

Peringatan